

# Bluetooth Wireless Stereo Headphones

## Quick Start Guide



aluratek.com

model ABH01F

qsg Q10405 Copyright © 2016 Aluratek, Inc. All Rights Reserved.

## Button Operation

**Transfer call:** During the phone call, press the ▲ button for 2 seconds to switch the call to your smartphone. Press the ▲ button for 2 seconds again to switch the call back to the headphones.

**Last number redial:** In standby status, press the ◀ button twice to redial the last number.

**Call Mute function:** Press the ▼ button for 2 seconds to mute a call in progress. Press the ▼ button for 2 seconds again to unmute the call.

**Battery Capacity status:** When the headphones are connected to an iOS device, the headphone battery power status is visible in the upper right corner.

**Reset Mode:** Connect the headphones to a computer via a micro USB cable. When the red LED flashes, the reset is complete.

## Package Contents

Your order has been carefully packaged and inspected. The following accessories should be included in your package. Please inspect the contents of the package to ensure that you have received all items and that nothing has been damaged. If you discover a problem, please contact us immediately for assistance.



USB Charging Cable



3.5 mm Cable



Registration Card

## Device Operation

### Charging the battery

The battery is not fully charged and it is highly recommended that you charge ABH01F before you begin using it.

Note: Using ABH01F "out of the box" will not harm the device. You will experience reduced battery life as the unit will not be fully charged.

Connect the larger USB end of the provided cable to your computer / power adapter (not included). Connect the smaller micro USB end to the USB port of ABH01F. Please charge the battery for a minimum of 3 hours. The red LED will be on while charging. When charging is complete, the blue LED will turn ON.

Function	Operation
Enter Pairing Mode	Ensure ABH01F is turned OFF. Press and hold the ◀ button for 6 seconds. Red and blue LED will flash rapidly.
Power ON / OFF	Press and hold the ◀ button for 2 seconds. A blue LED will flash twice for ON. A red LED will flash twice for OFF.

## Technical Support

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.


E-mail: [support@aluratek.com](mailto:support@aluratek.com)

Web: [www.aluratek.com/helpdesk](http://www.aluratek.com/helpdesk)

Local (Irvine, CA): 714-586-8730

Toll free: 1-866-580-1978

## Product Highlights



## Device Operation

Note: The pairing mode will last 10 minutes. ABH01F will power off automatically if no devices can be connected within 10 minutes.

### Pairing with an iPhone, smartphone or tablet:

The pairing procedure will vary depending on the actual device. Please refer to the user guide of your device for detail instruction. The pairing procedures are as follows:

1. Make sure the headphones are powered OFF.
2. To activate the headphone pairing mode, press and hold the ◀ button for 6 seconds. (Red and Blue LED will flash rapidly)
3. Activate your device's Bluetooth function and set your device to search for Bluetooth devices. Select ABT01FKIT when it is found.
4. For transmitter with Bluetooth version 2.1, you will not need to input a code. If you are prompted for PIN, please enter "0000".
5. If prompted by your device to connect, please select "Yes".
6. After connecting successfully, the blue LED will flash 3 times every 5 seconds.

Note: Please make sure the audio output is set to Bluetooth for audio streaming from the device.

## Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

## Button Operation

**Power On:** Press the ◀ button for 2 seconds. The blue LED will flash twice.

**Power Off:** Press the ◀ button for 3 seconds. The red LED will flash twice.

**Volume Adjust:** Press the ▲ or ▼ buttons to adjust the volume.

**Play/Pause:** Short press the ◀ button to play and pause music.

**Previous:** In standby status, long press the ▼ button for 2 seconds to return to the previous music track.

**Next:** In standby status, long press the ▲ button for 2 seconds to advance to the next music track.

**Answer Call:** Short press the ◀ button to answer phone calls.

**End call:** Short press the ◀ button to end the phone call.

**Reject call:** Press the ▲ button for 2 seconds to reject a call.

## Device Operation

### 3.5mm music line-in function

Connect the audio line-in 3.5mm cable to 3.5 audio jack for wired music.

1. Connect the 3.5 audio wire to the headphone and audio player.
2. You can adjust the volume from the connected audio player or mobile phone.

Note: Phone function cannot be used in this mode

## Warranty

Aluratek warrants this product against defect in material or workmanship for **1 YEAR** from the date of purchase.

This warranty becomes invalid if the factory-supplied serial number or "warranty void" sticker has been removed or altered on the product.

This warranty does not cover:

- A) Cosmetic damage or damage due to acts of God
- B) Accident, misuse, abuse, negligence or modification of any part of the product.
- C) Damage due to improper operation or maintenance, connection to improper equipment, or attempted repair by anyone other than Aluratek.
- D) Products sold AS IS or WITH FAULTS.

IN NO EVENT SHALL ALURATEK'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, IT'S ACCOMPANYING SOFTWARE, OR IT'S DOCUMENTATION.

Aluratek makes no warranty or representation, expressed, implied, or statutory, with respect to it's products, contents or use of this documentation and all accompanying software, and specifically disclaims it's quality, performance, merchantability, or fitness for any particular purpose. Aluratek reserves the right to revise or update it's product, software or documentation without obligation to notify any individual or entity.