

Bluetooth Wireless Sport Earbuds Quick Start Guide




ABH13F

aluratek.com

qsg Q10355 Copyright © 2014 Aluratek, Inc. All Rights Reserved.

Product Highlights



Operation

Charging the battery

The battery is not fully charged and it is highly recommended that you charge ABH13F before you begin using it.

Note: Using ABH13F "out of the box" will not harm the device. You will experience reduced battery life as the unit will not be fully charged.

Using the included USB cable, plug the small micro USB to the headset. Connect the larger USB end of the cable to your PC or a USB power adapter (not included).

Please charge the battery for a minimum of 2 hours. The Red LED will be on while charging. When charging is complete, the red LED will turn blue.



Operation

Operation

Operation

Battery Status Bar for iPhone

Function Table

Function	Operation	LED Indicator
Power On	Press and hold <i>Power</i> button for 3 seconds	Blue LED - 1 second
Power Off	Press and hold <i>Power</i> button for 3 seconds	Red LED - 1 second
Enter Pairing Mode	Ensure ABH13F is turned Off. Press and hold <i>Power</i> button for 5 seconds until LED flashes red and blue alternately	LED flashes red and blue alternately
Answer a Call	Short press <i>Answer</i> button once	
Reject a Call	Long press <i>Answer</i> button for 2 seconds	
End a Call	Short press <i>Answer</i> button once	

Function Table cont.

Function	Operation
Redial the Last Number	Press the <i>Answer</i> button twice
Next Song	Long press <i>Volume up</i> button
Previous Song	Long press <i>Volume down</i> button
Pause Song	Short press <i>Power / Play</i> button once
Play Song	Short press <i>Power / Play</i> button once

Note: The pairing mode will last 2 minutes. ABH13F will switch to the standby mode automatically if no devices can be connected within 2 minutes.

Pairing with the transmitter such as iPhone, smart phone, and tablet:

The pairing procedure will vary depending on the actual device. Please refer to the user guide of your device for detail instruction. The general pairing procedures are as follows:

1. Make sure ABH13F is turned Off.
2. Activate ABH13F pairing mode by pressing and holding the power / play button for 5 seconds.
3. Activate your device's Bluetooth function and set your device to search for Bluetooth devices. Select ABH13F when it is found.
4. For transmitter with Bluetooth version 2.1, you will not need to input a code. If you are prompted for PIN, please enter "0000".
5. If prompted by your device to connect, please select "Yes".
6. After connecting successfully, the blue LED will flash every 5 seconds.


Note: Please make sure the audio output is set to Bluetooth for audio streaming from the device.

When using ABH13F with an iPhone, an additional battery meter () will be activated and the remaining battery capacity will display on your phone.



Wearing the Earbuds

For the best sound performance and a secure, comfortable fit, be sure the ear buds rest gently in your ear and drape around the back of your neck. Use the provided fit kit to find the ear tip that works best for you.



Technical Support

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: support@aluratek.com
 Web: www.aluratek.com/support
 Local (Irvine, CA): 714-586-8730
 Toll free: 1-866-580-1978

Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

Warranty

Aluratek warrants this product against defect in material or workmanship for **1 YEAR** from the date of purchase.

This warranty becomes invalid if the factory-supplied serial number or "warranty void" sticker has been removed or altered on the product.

This warranty does not cover:

- A) Cosmetic damage or damage due to acts of God
- B) Accident, misuse, abuse, negligence or modification of any part of the product.
- C) Damage due to improper operation or maintenance, connection to improper equipment, or attempted repair by anyone other than Aluratek.
- D) Products sold AS IS or WITH FAULTS.

IN NO EVENT SHALL ALURATEK'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, IT'S ACCOMPANYING SOFTWARE, OR IT'S DOCUMENTATION.

Aluratek makes no warranty or representation, expressed, implied, or statutory, with respect to it's products, contents or use of this documentation and all accompanying software, and specifically disclaims it's quality, performance, merchantability, or fitness for any particular purpose. Aluratek reserves the right to revise or update it's product, software or documentation without obligation to notify any individual or entity.