

4 - Port USB Charging Station Quick Start Guide




AUCS04F

aluratek.com


qsg Q10376 Copyright © 2014 Aluratek, Inc. All Rights Reserved.

Device Controls




To insert:

Slide in AC plug until you hear the plug click into place.



To remove:

Hold down on the release button to slide out the AC plug.



Tech Support & Warranty Information

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: support@aluratek.com
Web: www.aluratek.com/support
Local (Irvine, CA): 714-586-8730
Toll free: 1-866-580-1978

Aluratek warrants this product against defect in material or workmanship for **1 Year** from the date of purchase.

For more information, please visit: <http://aluratek.com/warranty-return-policy>

You can register your product online at: <http://aluratek.com/product-registration>

Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

4 -Port Station de recharge USB Guide de démarrage rapide




AUCS04F

aluratek.com


qsg Q10376 Copyright © 2014 Aluratek, Inc. Tous droits réservés.

Contrôles de l'appareil




Pour insérer :

Faites glisser la prise secteur jusqu'à ce que vous entendez Cliquez sur la fiche en place .



Pour supprimer :

Maintenez sur le bouton de déverrouillage à glisser le Fiche secteur .



Support Technique & Information sur la garantie

Si vous avez besoin d'aide, s'il vous plaît contacter le département de support Aluratek pour le dépannage avant de retourner cet appareil.

E-mail: support@aluratek.com
Web: www.aluratek.com/support
Local (Irvine, CA): 714-586-8730
Sans frais: 1-866-580-1978

Aluratek garantit ce produit contre tout défaut de matériel ou de fabrication pour les **1 an** à partir de la date d'achat.

Pour plus d'informations, s'il vous plaît visitez le site: <http://aluratek.com/warranty-return-policy>

Vous pouvez enregistrer votre produit en ligne à: <http://aluratek.com/product-registration>

Énoncé d'interférence avec la réception radio et télévisée

AVERTISSEMENT!!! Cet appareil a été testé et est conforme aux limites d'un appareil numérique de Classe B, en vertu de la Section 15 des règles CFC. Ces limites ont été conçues pour assurer une protection raisonnable contre de telles interférences néfastes dans une installation résidentielle.

Cet équipement génère, utilise et peut émettre de l'énergie de fréquence radio. S'il n'est pas correctement installé et utilisé, il peut causer des interférences nuisibles dans les communications radio. Toutefois, il est impossible de garantir que de telles interférences ne surviendront pas dans une installation particulière. Si cet équipement cause des interférences nuisibles à la réception radio ou télévisée, laquelle peut être déterminée en éteignant et allumant l'équipement, on suggère à l'utilisateur d'essayer de corriger l'interférence par quelques mesures que ce soit afin d'éliminer les interférences.